

Link
tech

PREMIUM
VIP PRODUCT

Hello!

Model: LPH-SE41

True Wireless Metal Earbuds

User Manual

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Customer

Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.

Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.

Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.

If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.

LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.

LinkTech's Sales Team

Ultra Slim Metal Case Wireless Earbuds



ENC | 4 Microphones
for clearer calls

SE41 blends premium sound quality with a sleek zinc metal casing, minimalist design, advanced touch controls, and IPX4 water resistance for a versatile audio experience with a style



User's Manual

We recommend using the cable that was included in the package to charge the earphones

Contents List



User's Manual/ Warranty Card (1PCS)



USB-A to USB Type-C
Charging Cable (1PCS)



Charging Case
(1 PCS)



TWS earphones
(2 PCS)

Product Characteristics and Features

- IPX4 water resistance
- Very comfortable in-ear design with ergonomic touch control
- Ultra slim metal charging case
- Large 13mm dynamic drivers optimized to deliver a rich and deep bass sound
- Smart touch controls, to control your music and calls with a tap of a finger.
- Environmental Noise Cancellation (ENC): enhances voice clarity during calls by reducing background noise with embedded quad mic
- Bluetooth v5.4 Wireless Technology support, with TWS feature to connect two devices at the same time

Safe Use Information

Read the instructions carefully before use, appearance and specifications of the device may be resized and different from the image in this manual without prior notice.

- ⚠ Do not listen to music at maximum volume for long periods of time as this can damage your hearing.
- ⚠ Consult a physician regarding the use of this device with medical equipment, or consult a medical device manufacturer for this matter
- ⚠ Use only certified wall chargers.

Product Specifications

Bluetooth Chipset IC	JL6973
Bluetooth Version	V5.4 with TWS feature
Bluetooth Protocol	HFP, A2DP, HSP, AVRCP
BT Decoding Mode	SBC, AAC
Frequency Response	20Hz ~ 20KHz
Sensitivity	112dB ±3dB
Audio Drivers	Ø13mm Dynamic, 3~5mW
Impedance	32Ω
Materials	Zinc Alloy
Transmission Distance	Approximately 10m
Water Resistance Level	IPX4
Battery Type	Li-ion Polymer
Charging Port	USB Type-C
Charging Time	~ 2 Hours
Earbuds Charging time	~ 1 Hours
Charging Case's Battery	3.7V / 300mAh
Earbuds' Battery	2X 30mAh
Playing Time	4 hours (Earbuds) + 12 hours (Charging Case)
Charging Input	DC 5V / 1A
Dimensions	85.4mm X 34.5mm X 19.2mm
Weight	3.8g Earbud / 67.2g Charging Case



Do not do the following with the device and battery

- Do not disassemble it on your own
- Do not repair it on your own
- Do not try to modify it
- Do not overheat the battery
- Do not expose it to direct sunlight
- DO not immerse it in water
- Keep it away from sources of fire or open flame
- Do not expose this product to very low or very high temperatures, below 0°C or above 45°C
- Contact an authorized service technician.



Do not use this product during a thunderstorm, there is a risk of electric shock or device malfunction.



The metal contacts (Figure 2 (point 5)) of the headphones and charging case must be free of dirt and not covered by foreign objects.



Do not use this device in places with strong exposure to an electromagnetic field, this can lead to incorrect operation or damage the device.


Figure 1

1. Metallic Charging Case
2. LED Indicator (Case battery's Charge Status)
3. Charging Port (USB Type-C)



Figure 2

1. Microphone
2. LED indicator (Charge Status and Earbuds Pairing)
3. Multi-function Touch Control
4. Metal contacts for charging




Quick Start Guide

1. Before using the device, remove the earbuds from the case and remove the protective film from the charging contacts of the earbuds.




2. Fully charge the case along with the headphones, use the supplied cable (power adapter is not included).



3. 4 LEDs Bar Indicator for showing the charging status of the case:

- 25% or less battery charge
- 25~50% battery charge
- 50~75% battery charge
- 75% or more battery charge



Use Steps:

1. Take the earbuds out of the charging case, they will automatically turn on (Figure 3), The voice prompt "power on" will sound in the earbuds to indicate that the earbuds are turned on.



2. Turn on Bluetooth on the device you want to pair with (smartphone, table, laptop, etc...)(Figure 4), Select Link-SE41 from the list of devices available for pairing, The voice prompt "connected" will sound in the earbuds, this means the earbuds are paired with your device.



3. The headphones are equipped with smart touch controls, The sensor area is shown in (Figure 5), Control is carried out by short or long pressing or a combination of pressings (see the table of operations in this user manual.)







4. When you are finished listening to music, put the earbuds back into the charging case (Figure 6), The earbuds will automatically turn off and start charging from the case battery.



Earbuds LED Indication

Charging	Steady white light while charging, the light will turn off when the charge is completed
Pairing mode	One earbud flashes white light quickly (2 times per second), the other earbud flashes white light slowly (one time per 5 seconds)
Connected	Without light
Incoming call	White light flash 2 times per 500ms
Two earphones pairing	White light flash quickly
Charging to the case	4 Light Bar Indicator, each turned on LED will correspond for 25% of charge (25%,50%75%,100%)
Case is fully charged	White LED is off
Notice	Use an AC adapter with 5V output voltage (compatible) with a USB Type-C cable.

Touch Operation Table

	Left		Right	
 Single Tap	 Play/ Pause	 Answer Call	 Play/ Pause	 Answer Call
 Double Tap	 Previous Track	 End Call	 Next Track	 End Call
 Triple Tap	 Voice Assistant		 Siri	
 Tap and hold the touch control of the earbud for 2 seconds	 Decrease Volume	 Reject call	 Increase Volume	 Reject call

Power on (Hall Switch)

1. open the charging case
2. if the earbuds are out of the charging case, long press around 2s to power on

Power off (Hall Switch)

1. put the earbuds into charging case then close it
2. to disconnect the earbuds from the phone without putting them into the case, long press for 5s L/R to power off

Your smartphone (or any other device that is paired with the earbuds must be connected to the Internet, and have support for Siri or any similar voice assistant function.

Note: Volume control not available when using one side only, others functions remain the same.

To Reset the earbuds to factory settings and synchronize left and right earbuds: With short quick presses, touch the left and right earbuds at the same time 5 times.

Before that, remove Link-SE41 from the list of paired Bluetooth devices on your phone.



Imalatçı Firma
LINK-TECH TRADING COMPANY LIMITED
FLAT 609A,6/F. FOOK CHONG BUILDING 63 HUI YUEN
ROAD, KWUN TONG, KOWLOON, HONG KONG
TEL: 3114 7567